



Remove alignment pin from the top of the motor cover using the Allen wrench provided.



Place EMS shelf over the motor cover and use hole that is closest to the front of the machine.



Place alignment pin through the shelf into the motor cover and tighten with the Allen wrench provided. Place shelf into desired position and tighten the screw to lock the shelf into place.

